



NOTES TO DESIGNER:

1. INSTALL FIRST Techline® EZ LOOP 18-INCHES FROM CENTER OF TREE TRUNK. INSTALL EACH ADDITIONAL LOOP PER NETAFIM INSTALLATION GUIDELINES.
2. INSTALL Techline® EZ DRIPLINE ON SURFACE TO MAXIMUM OF 6-INCHES BELOW GRADE, STAPLE IN PLACE PER MANUFACTURER'S RECOMMENDATIONS, BACKFILL AND SPREAD SURFACE TREATMENT AS DIRECTED BY OTHERS.
3. INSTALL Techline® EZ IN ACCORDANCE WITH NETAFIM INSTALLATION GUIDELINES.
4. FOR ON SURFACE APPLICATION.

00

Techline® EZ TWO TREE RING LAYOUT

NOT TO SCALE



DETAIL - EZ132