

# 1 1/2" MANUAL DISC FILTER

## INSTALLATION, OPERATION & MAINTENANCE INSTRUCTIONS

## **FEATURES**

- A "T' shaped reinforced plastic filter with two 1 ½" male connections.
- Filter element consists of grooved discs, mounted on a spine, forming a cylindrical filter element. The discs are compressed together by a spring located at the bottom of the filter cover.
- · Screw-on filter cover.
- · Resistant to chemicals and liquid fertilizers.
- Available filtration grades: 040, 080, 120, 140 and 200.

<b>TECHNICAL DATA</b>		
FLOW RANGE	10 - 35 GPM	
MAXIMUM PRESSURE	140 psi	
FILTERING SURFACE AREA	49 sq. in.	
FILTERING VOLUME	27 cu. in.	
LENGTH	10 5/8"	
WIDTH	7 7/8"	
WEIGHT	2.4 lbs.	
DISTANCE BETWEEN ENDS	7 7/8"	
INLET/OUTLET DIAMETER	1½" Male	
MAXIMUM TEMPERATURE	158° F	
pH	5 - 11	



MESH/MICRON				
MESH	MICRON	DISC COLOR		
040	400	Blue		
080	200	Yellow		
120	130	Red		
140	115	Black		
200	55	Green		

## **INSTALLATION**

- 1. Filter can be installed either vertically or horizontally.
- 2. Use Teflon tape on filter threads Do Not Use Pipe Dope.
- 3. Ensure correct inlet/outlet direction.
- 4. When connecting filter to pipe, do not overtighten.
- 5. Never use spanners for tighening the filter cover.

## **MAINTENANCE AND CLEANING**


## **DISMANTLING**

- 1. Ensure system is turned off and no pressure remains in the pipeline.
- 2. Unscrew cover from the filter body.
- 3. Pull out entire filter element.


#### **CLEANING**

- 1. Move tightening ring to end of spine and flush discs with pressurized water.
- 2. If discs are not clean after flushing with water:
  - a. If the discs have an accumulation of algae in the grooves soak the discs and spine in a small bucket of Clorox bleach for one hour and then reflush with fresh water.
  - b. If the discs have an accumulation of iron in the grooves, soak the discs and spine in a small bucket of 10% Muriatic Acid for one hour and then reflush with fresh water.
    Muriatic Acid can be purchased at any pool supply store.

#### TOP VIEW



## FRONT VIEW





## **MAINTENANCE AND CLEANING**

## **ASSEMBLY**

- 1. Verify that spring is in place inside the filter cover.
- 2. Insert filter element and make sure it is seated correctly.
- 3. Replace cover.
- 4. Tighten filter cover securely by turning the fixing nut clockwise and do not overtighten.


## **WINTERIZATION**

Drain all the water from the filter to avoid cracking due to freezing.

PARTS BREAKDOWN - 1.5" FILTER				
KEY	MODEL NUMBER	DESCRIPTION	MATERIALS	
1	SEE # 11	GAUGE PORT NUT	R.PP	
2	SEE # 11	GAUGE PORT SEAL	EPDM	
3	-	FILTER ADAPTER RING	R.PP	
4	25AP531140	COVER O RING	R.PP	
5	25AP531130	COMPRESSION SPRING	NR	
6	25AP23113	FILTER COVER	SS	
7	-	1/4" TAP (OPTIONAL)	BRASS	
8	25AP231131	FIXING NUT	R.PA	
9	25AP131199	FILTER WRENCH	PP	
10	25AP47-***	RING SET WITH SPINE	R.PA	
11	25AP231511	FILTER BODY COMPLETE	-	

Substitute \*\*\* for proper mesh size.

MATERIALS KEY			
CODE	MATERIAL		
SS	STAINLESS STEEL		
PP	POLYPROPYLENE		
NR	NITRILE RUBBER		
R.PP	REINFORCED POLYPROPYLENE		
R.PA	REINFORCED POLYAMIDE		
EPDM	ETH. PROPY. RUBBER		





5470 E. Home Ave. Fresno, CA 93727 888.638.2346 • 559.453.6800 FAX 800.695.4753 www.netafimusa.com